



HR	Cisco IOS XR Interface and Hardware Component Command Reference
IR	Cisco IOS XR IP Addresses and Services Command Reference
MCR	Cisco IOS XR Multicast Command Reference
MPR	Cisco IOS XR MPLS Command Reference
QR	Cisco IOS XR Modular Quality of Service Command Reference
RR	Cisco IOS XR Routing Command Reference
SMR	Cisco IOS XR System Management Command Reference
SR	Cisco IOS XR System Security Command Reference

A

address-family (BGP) command	RR-2
address-family (IS-IS) command	RR-258
address-family (OSPF) command	RR-414
address-family (OSPFv3) command	RR-554
adjacency-check disable command	RR-259
advertisement-interval command	RR-4
af-group command	RR-6
aggregate-address command	RR-8
apply command	RR-706
area (OSPF) command	RR-415
area (OSPFv3) command	RR-555
as-path in command	RR-708
as-path is-local command	RR-710
as-path length command	RR-711
as-path neighbor-is command	RR-713
as-path originates-from command	RR-715
as-path passes-through command	RR-717
as-path-set command	RR-719
as-path unique-length command	RR-721
authentication (OSPF) command	RR-416
authentication (OSPFv3) command	RR-556
authentication-key (OSPF) command	RR-418
auto-cost (OSPF) command	RR-420
auto-cost (OSPFv3) command	RR-558

B

bgp as-path-loopcheck command	RR-10
bgp attribute-download command	RR-11
bgp auto-policy-soft-reset disable command	RR-12
bgp bestpath as-path ignore command	RR-13
bgp bestpath compare-routerid command	RR-15
bgp bestpath med always command	RR-16
bgp bestpath med confed command	RR-18
bgp bestpath med missing-as-worst command	RR-20
bgp client-to-client reflection disable command	RR-21
bgp cluster-id command	RR-23
bgp confederation identifier command	RR-25
bgp confederation peers	RR-27
bgp dampening command	RR-28
bgp default local-preference command	RR-30
bgp enforce-first-as disable command	RR-31
bgp fast-external-fallover disable command	RR-32
bgp graceful-restart command	RR-33
bgp graceful-restart graceful-reset command	RR-35
bgp graceful-restart purge-time command	RR-36
bgp graceful-restart restart-time command	RR-37
bgp graceful-restart stalepath-time command	RR-38
bgp log neighbor changes disable command	RR-39
bgp maximum neighbor command	RR-41
bgp redistribute-internal command	RR-42
bgp router-id command	RR-44
bgp scan-time command	RR-46
bgp update-delay command	RR-47
bgp write-limit command	RR-48

C

capability opaque command	RR-422
capability orf prefix-list command	RR-50

circuit-type command [RR-260](#)
 clear bgp command [RR-52](#)
 clear bgp dampening command [RR-54](#)
 clear bgp flap-statistics command [RR-56](#)
 clear bgp peer-drops command [RR-58](#)
 clear bgp performance-statistics command [RR-59](#)
 clear bgp self-originated command [RR-60](#)
 clear bgp shutdown command [RR-61](#)
 clear bgp soft command [RR-62](#)
 clear isis process command [RR-262](#)
 clear isis route command [RR-263](#)
 clear isis statistics command [RR-264](#)
 clear ospf process command [RR-423](#)
 clear ospf redistribution command [RR-424](#)
 clear ospf routes command [RR-425](#)
 clear ospf statistics command [RR-426](#)
 clear ospfv3 process command [RR-560](#)
 clear ospfv3 redistribution command [RR-561](#)
 clear ospfv3 routes command [RR-562](#)
 clear ospfv3 statistics command [RR-563](#)
 clear route command [RR-682](#)
 community is-empty command [RR-723](#)
 community matches-any command [RR-724](#)
 community matches-every command [RR-726](#)
 community-set command [RR-728](#)
 cost (OSPF) command [RR-428](#)
 cost (OSPFv3) command [RR-565](#)
 csnp-interval command [RR-266](#)

D

database-filter all out (OSPF) command [RR-430](#)
 database-filter all out (OSPFv3) command [RR-567](#)
 dead-interval (OSPF) command [RR-432](#)
 dead-interval (OSPFv3) command [RR-569](#)
 default-cost (OSPF) command [RR-434](#)
 default-cost (OSPFv3) command [RR-571](#)
 default-information originate (BGP) command [RR-64](#)
 default-information originate (IS-IS) command [RR-268](#)

default-information originate (OSPF) command [RR-436](#)
 default-information originate (OSPFv3) command [RR-573](#)
 default-metric (BGP) command [RR-65](#)
 default-metric (OSPF) command [RR-438](#)
 default-metric (OSPFv3) command [RR-575](#)
 default-originate command [RR-66](#)
 delete community command [RR-730](#)
 delete extcommunity command [RR-732](#)
 demand-circuit (OSPF) command [RR-440](#)
 demand-circuit (OSPFv3) command [RR-576](#)
 description (BGP) command [RR-68](#)
 destination in command [RR-734](#)
 disable (IS-IS) command [RR-270](#)
 distance (IP) command [RR-441](#)
 distance (ISIS) command [RR-271](#)
 distance bgp command [RR-69](#)
 distance ospf command [RR-443](#)
 distance ospfv3 command [RR-578](#)
 distribute-list command [RR-445](#)
 distribute-list prefix-list in command [RR-580](#)
 distribute-list prefix-list out command [RR-582](#)
 dmz-link-bandwidth command [RR-71](#)
 drop command [RR-736](#)

E

ebgp-multihop command [RR-73](#)
 edit command [RR-738](#)
 end-policy command [RR-740](#)
 end-set command [RR-741](#)
 extcommunity is-empty command [RR-742](#)
 extcommunity matches-every command [RR-745](#)
 extcommunity-set command [RR-747](#)

F

flood-reduction (OSPF) command [RR-447](#)
 flood-reduction (OSPFv3) command [RR-584](#)

H

hello-interval (IS-IS) command [RR-273](#)
 hello-interval (OSPF) command [RR-449](#)
 hello-interval (OSPFv3) command [RR-586](#)
 hello-multiplier command [RR-275](#)
 hello-padding command [RR-277](#)
 hello-password accept command [RR-281](#)
 hello-password command [RR-279](#)
 hostname dynamic disable command [RR-282](#)

I

if command [RR-749](#)
 ignore lsa mospf command [RR-451](#)
 ignore-lsp-errors command [RR-284](#)
 instance command [RR-588](#)
 interface (IS-IS) command [RR-285](#)
 interface (OSPF) command [RR-452](#)
 interface (OSPFv3) command [RR-590](#)
 ispf command [RR-287](#)
 ispf startup-delay command [RR-288](#)
 is-type command [RR-290](#)

L

local-as command [RR-75](#)
 log adjacency changes (IS-IS) command [RR-292](#)
 log adjacency changes (OSPF) command [RR-454](#)
 log adjacency changes (OSPFv3) command [RR-592](#)
 log pdu drops command [RR-294](#)
 lsp-gen-interval command [RR-295](#)
 lsp-interval command [RR-297](#)
 lsp-mtu command [RR-298](#)
 lsp-password accept command [RR-302](#)
 lsp-password command [RR-300](#)
 lsp-refresh-interval command [RR-303](#)

M

maximum interfaces (OSPF) command [RR-457](#)
 maximum interfaces (OSPFv3) command [RR-593](#)
 maximum-paths (BGP) command [RR-77](#)
 maximum-paths (IS-IS) command [RR-305](#)
 maximum-paths (OSPF) command [RR-458](#)
 maximum paths (OSPFv3) command [RR-594](#)
 maximum-prefix command [RR-78](#)
 maximum redistributed-prefix command [RR-459](#)
 maximum-redistributed-prefixes (IS-IS)
 command [RR-306](#)
 maximum redistributed-prefixes command [RR-595](#)
 max-lsp-lifetime command [RR-307](#)
 max-metric command [RR-455](#)
 med command [RR-753](#)
 mesh-group (IS-IS) command [RR-308](#)
 message-digest-key command [RR-461](#)
 metric command [RR-310](#)
 metric-style narrow command [RR-312](#)
 metric-style transition command [RR-314](#)
 metric-style wide command [RR-316](#)
 mpls traffic-eng area (OSPF) command [RR-463](#)
 mpls traffic-eng command [RR-318](#)
 mpls traffic-eng router-id (IS-IS) command [RR-319](#)
 mpls traffic-eng router-id (OSPF) command [RR-465](#)
 mtu-ignore (OSPF) command [RR-467](#)
 mtu-ignore (OSPFv3) command [RR-597](#)

N

neighbor (BGP) command [RR-80](#)
 neighbor (OSPF) command [RR-469](#)
 neighbor (OSPFv3) command [RR-599](#)
 neighbor database-filter all out command [RR-471](#)
 neighbor-group command [RR-82](#)
 net command [RR-321](#)
 network (BGP) command [RR-84](#)
 network (OSPF) command [RR-472](#)

network (OSPFv3) command [RR-601](#)
network backdoor command [RR-86](#)
next-hop in command [RR-755](#)
next-hop-self command [RR-88](#)
nsf (IS-IS) command [RR-323](#)
nsf (OSPF) command [RR-474](#)
nsf interface-expires command [RR-324](#)
nsf interface-timer command [RR-326](#)
nsf interval (OSPF) command [RR-476](#)
nsf lifetime (IS-IS) command [RR-328](#)
nsf lifetime (OSPF) command [RR-477](#)
nssa (OSPF) command [RR-478](#)
nssa (OSPFv3) command [RR-603](#)

O

origin is command [RR-756](#)
ospf name-lookup command [RR-479](#)
ospfv3 name-lookup command [RR-605](#)

P

packet-size command [RR-480](#)
pass command [RR-758](#)
passive (IS-IS) command [RR-329](#)
passive (OSPF) command [RR-481](#)
passive (OSPFv3) command [RR-606](#)
password command [RR-90](#)
password-disable command [RR-92](#)
point-to-point command [RR-330](#)
prefix-list command [RR-94](#)
prefix-set command [RR-759](#)
prepend as-path command [RR-761](#)
priority (IS-IS) command [RR-331](#)
priority (OSPF) command [RR-483](#)
priority (OSPFv3) command [RR-608](#)
propagate level command [RR-332](#)

R

range (OSPF) command [RR-485](#)
range (OSPFv3) command [RR-610](#)
receive-buffer-size command [RR-96](#)
redistribute (BGP) command [RR-98](#)
redistribute (IS-IS) command [RR-334](#)
redistribute (OSPF) command [RR-487](#)
redistribute (OSPFv3) command [RR-612](#)
remote-as (BGP) command [RR-101](#)
remove-private-as command [RR-103](#)
retransmit-interval (IS-IS) command [RR-337](#)
retransmit-interval (OSPF) command [RR-491](#)
retransmit-interval (OSPFv3) command [RR-616](#)
retransmit-throttle-interval command [RR-339](#)
rib-has-route command [RR-763](#)
route command [RR-886](#)
route maximum command [RR-889](#)
route-policy command [RR-105, RR-764](#)
router bgp command [RR-109](#)
route-reflector-client [RR-107](#)
router-id (OSPF) command [RR-493](#)
router-id (OSPFv3) command [RR-618](#)
router isis command [RR-341](#)
router ospf command [RR-495](#)
router ospfv3 command [RR-620](#)
route-type is command [RR-766](#)
rpl maximum command [RR-768](#)

S

send-buffer-size command [RR-110](#)
send-community-ebgp command [RR-112](#)
send-extended-community-ebgp command [RR-114](#)
session-group command [RR-116](#)
session-open-mode command [RR-118](#)
set-attached-bit command [RR-342](#)
set community command [RR-770](#)
set cost command [RR-772](#)

- set dampening command [RR-773](#)
- set extcommunity command [RR-775](#)
- set level command [RR-777](#)
- set local-preference command [RR-778](#)
- set med command [RR-779](#)
- set metric command [RR-781](#)
- set metric-type (IS-IS) command [RR-782](#)
- set metric-type (OSPF) command [RR-783](#)
- set next-hop command [RR-784](#)
- set origin command [RR-786](#)
- set-overload-bit command [RR-344](#)
- set tag command [RR-787](#)
- set traffic-index command [RR-788](#)
- set weight command [RR-790](#)
- show bgp advertised command [RR-127](#)
- show bgp af-group command [RR-133](#)
- show bgp attribute-key command [RR-136](#)
- show bgp cidr-only command [RR-140](#)
- show bgp command [RR-120](#)
- show bgp community command [RR-144](#)
- show bgp convergence command [RR-148](#)
- show bgp count-only command [RR-151](#)
- show bgp dampened-paths command [RR-154](#)
- show bgp flap-statistics command [RR-157](#)
- show bgp inconsistent-as command [RR-161](#)
- show bgp neighbor-group command [RR-165](#)
- show bgp neighbors command [RR-168](#)
- show bgp paths command [RR-182](#)
- show bgp policy command [RR-184](#)
- show bgp process command [RR-191](#)
- show bgp regexp command [RR-206](#)
- show bgp route-policy command [RR-210](#)
- show bgp session-group command [RR-214](#)
- show bgp summary command [RR-217](#)
- show bgp truncated-communities command [RR-220](#)
- show bgp update-group command [RR-224](#)
- show isis adjacency command [RR-346](#)
- show isis adjacency-log command [RR-349](#)
- show isis checkpoint adjacency command [RR-351](#)
- show isis checkpoint interface command [RR-353](#)
- show isis checkpoint lsp command [RR-354](#)
- show isis database command [RR-356](#)
- show isis database-log command [RR-363](#)
- show isis hostname command [RR-365](#)
- show isis interface command [RR-367](#)
- show isis lsp-log command [RR-371](#)
- show isis mesh-group command [RR-374](#)
- show isis mpls traffic-eng adjacency-log command [RR-376](#)
- show isis mpls traffic-eng advertisements command [RR-378](#)
- show isis mpls traffic-eng tunnel command [RR-380](#)
- show isis neighbors command [RR-382](#)
- show isis protocol command [RR-385](#)
- show isis route command [RR-387](#)
- show isis spf-log command [RR-389](#)
- show isis statistics command [RR-395](#)
- show isis topology command [RR-398](#)
- show ospf border-routers command [RR-498](#)
- show ospf command [RR-496](#)
- show ospf database command [RR-500](#)
- show ospf flood-list command [RR-511](#)
- show ospf interface command [RR-513](#)
- show ospf mpls traffic-eng command [RR-515](#)
- show ospf neighbor command [RR-520](#)
- show ospf request-list command [RR-526](#)
- show ospf retransmission-list command [RR-528](#)
- show ospf route command [RR-530](#)
- show ospf summary-prefix command [RR-533](#)
- show ospfv3 border-routers command [RR-624](#)
- show ospfv3 command [RR-621](#)
- show ospfv3 database command [RR-626](#)
- show ospfv3 flood-list command [RR-637](#)
- show ospfv3 interface command [RR-639](#)
- show ospfv3 neighbor command [RR-642](#)
- show ospfv3 retransmission-list command [RR-651](#)
- show ospfv3 route command [RR-653](#)
- show ospfv3 summary-prefix command [RR-655](#)

- show ospfv3 virtual-links command [RR-657](#)
 show ospf virtual-links command [RR-535](#)
 show ospv3 request-list command [RR-648](#)
 show protocols (BGP) command [RR-229](#)
 show protocols (IS-IS) command [RR-401](#)
 show protocols (OSPF) command [RR-537](#)
 show protocols (OSPFv3) command [RR-659](#)
 show route command [RR-684](#)
 show route connected command [RR-692](#)
 show route local command [RR-694](#)
 show route longer-prefixes command [RR-696](#)
 show route static command [RR-700](#)
 show route summary command [RR-702](#)
 show rpl active as-path-set command [RR-792](#)
 show rpl active community-set command [RR-795](#)
 show rpl active extcommunity-set command [RR-798](#)
 show rpl active prefix-set command [RR-803](#)
 show rpl active route-policy command [RR-801](#)
 show rpl as-path-set attachpoints command [RR-808](#)
 show rpl as-path-set command [RR-806](#)
 show rpl as-path-set references command [RR-811](#)
 show rpl community-set attachpoints command [RR-816](#)
 show rpl community-set command [RR-814](#)
 show rpl community-set references command [RR-818](#)
 show rpl extcommunity-set attachpoints command [RR-823](#)
 show rpl extcommunity-set command [RR-821](#)
 show rpl extcommunity-set references command [RR-826](#)
 show rpl inactive as-path-set command [RR-829](#)
 show rpl inactive community-set command [RR-832](#)
 show rpl inactive extcommunity-set command [RR-835](#)
 show rpl inactive prefix-set command [RR-838](#)
 show rpl inactive route-policy command [RR-841](#)
 show rpl maximum command [RR-844](#)
 show rpl prefix-set attachpoints command [RR-848](#)
 show rpl prefix-set command [RR-846](#)
 show rpl prefix-set references command [RR-851](#)
 show rpl route-policy attachpoints command [RR-856](#)
 show rpl route-policy command [RR-853](#)
 show rpl route-policy references command [RR-859](#)
 show rpl route-policy uses command [RR-862](#)
 show rpl unused as-path-set command [RR-865](#)
 show rpl unused community-set command [RR-868](#)
 show rpl unused extcommunity-set command [RR-871](#)
 show rpl unused prefix-set command [RR-874](#)
 show rpl unused route-policy command [RR-877](#)
 shutdown (BGP) command [RR-231](#)
 shutdown (IS-IS) command [RR-404](#)
 single-topology command [RR-405](#)
 socket-receive-buffer-size command [RR-233](#)
 socket send-buffer-size command [RR-235](#)
 soft-reconfiguration inbound command [RR-237](#)
 source in command [RR-880](#)
 spf-interval command [RR-407](#)
 stub (OSPF) command [RR-540](#)
 stub (OSPFv3) command [RR-661](#)
 summary-prefix (IS-IS) command [RR-409](#)
 summary-prefix (OSPF) command [RR-542](#)
 summary-prefix (OSPFv3) command [RR-663](#)
 suppressed (IS-IS) command [RR-411](#)
 suppress-route command [RR-882](#)
-
- T**
 table-policy command [RR-240](#)
 tag command [RR-883](#)
 timers (BGP) command [RR-242](#)
 timers bgp command [RR-244](#)
 timers lsa arrival command [RR-665](#)
 timers lsa group-pacing command [RR-544](#)
 timers lsa min-arrival command [RR-545](#)
 timers pacing flood command [RR-666](#)
 timers pacing lsa-group command [RR-668](#)
 timers pacing retransmission command [RR-670](#)
 timers throttle lsa all (OSPF) command [RR-546](#)
 timers throttle lsa-all command [RR-672](#)
 timers throttle spf (OSPF) command [RR-547](#)
 timers throttle spf (OSPFv3) command [RR-674](#)
 transmit-delay (OSPF) command [RR-548](#)

transmit-delay (OSPFv3) command [RR-676](#)

ttl-security command [RR-246](#)

U

update-source command [RR-249](#)

use command [RR-251](#)

V

virtual-link (OSPF) command [RR-550](#)

virtual-link (OSPFv3) command [RR-678](#)

W

weight command [RR-255](#)

